

**Wisconsin Wastewater Operators Association
Annual Meeting, Stevens Point, WI October 23-25, 2013
Fixed Film Moving Media for Wastewater Treatment**

**KENNETH E. NEU, M.S.
ENVIRONMENTAL / HEALTH
PRODUCTS & SERVICE**

**PO Box 21
Richfield, WI 53076**

**P. O. BOX 101
PHILLIPS, WI 54555**

**Business Cell: 262-628-1300
E-MAIL: ken-ehs@juno.com**

Title & Authors

When less is Truly MORE—the Next Generation of MBBR Technology--- Small Media Biofilm in a Continuous Flow Intermittent Cleaning Mode

Laura R. Marcolini¹, Ken Neu², Bjorn Rusten³

¹Biowater Technology, LLC, 2155 Diamond Hill Rd, Cumberland, RI 02864, USA

²Environmental/Health Products and Service, PO Box 101 Phillips, WI 54555, USA (submitter/presenter)

³Aquateam, P.O. Box 6875, Rodelokka, N-0504 Oslo, Norway

Contents of Presentation

- **Brief Overview of Fixed Film Moving Media**
- **Advantages & Examples**
- **The Next Generation:**
Continuous Flow Intermittent Cleaning



Brief Overview of Fixed Film Moving Media

Fixed Film Moving Media Reactor Treatment

- ❑ Developed in the 1980's primarily by Kaldnes Co. in Norway in collaboration with Trondheim University, Dr. Halvard Odegard & Dr. Bjorn Rusten.
- ❑ Moving Bed Biofilm Reactor (MBBR) is a general term used to describe the process. Initially MBBR was designed as a **Single Pass WWT process**

Moving Bed Biofilm Reactor Technology

- Biological process—toxicity rules apply
- Requires primary treatment, FOG < 100 mg/l
- Treatment design & configuration is arranged according to inlet & outlet parameters, including WW temp.
- Organic and Hydraulic loading is variable, dependent on Infl. parameters , Eff. goals.

Fixed Film Moving Media Reactor Treatment

Sample of Biofilm Carriers




Fixed Film Moving Media Reactor Treatment



- ❑ Carriers move throughout tank with aeration or by movement of water by mixers in an anoxic tank. No unused space in Reactor.
- ❑ Intimate contact of biomass w/ substrate & air
- ❑ Standard MBBR maximum media fill fraction
 - ❑ = 66 % fill of media in the reactor
- ❑ Media Retention Screen(s) keeps media in tank


Fixed Film Moving Media Reactor Treatment

Moving Media system, Aerobic and Anoxic modes, typical Biofilm Carrier Elements.



Fixed Film Moving Media Reactor Treatment





Advantages & Examples

Fixed Film Moving Media Reactor Treatment

Advantages:

- ☐ **Continuous process; Self-Cleaning Carrier Elements**
- ☐ **Operates as once-through (traditional MBBR) or multiple recirculation (IFAS, CFAS®)**
- ☐ **Cost-effective, compact design**
- ☐ **Stable & robust process: handles hydraulic and organic load variations**


Fixed Film Moving Media Reactor Treatment

Advantages:

EASY UPGRADING OF ACTIVATED SLUDGE PLANTS TO HIGHER CAPACITIES


- ❑ addition within the Activated Sludge unit process to achieve IFAS / CFAS status, and
- ❑ added as a separate unit process- within Flow Path, upstream or downstream of existing Fixed Film, AS or Lagoon.

Complete Mix Fixed Film (CMFF®)




- Once-through, no RAS, no MLSS
- BOD, COD removal at high loads:
 - * Municipal $> 17 \text{ Kg/m}^3\text{-day}$
 - * Industrial $\leq 17 \text{ Kg/m}^3\text{-day}$
- Nitrogen removal with low HRT: $< 3 \text{ mg/L}$ with 6 hr HRT
- Small footprint
- Operator friendly
- CSTR conditions, homogeneous bed, continuous solids sloughing

CMFF[®] - Activated Sludge



- Eliminates sludge bulking on high-loaded MLSS
 - * (SVI reductions >300 down to < 100)
- Stabilizes organic removal:
 - * Installations with 10x load fluctuations
 - * CMFF[®] process providing 80-90% organic removal
- Small footprint (0.5 hour HRT or greater)
- Low Implementation Cost

Combined Fixed Film and Activated Sludge[®] (CFAS)



- Biomass = MLSS & Biofilm
- Compartmentalize BOD Removal, Nitrification, and Nitrogen Removal
- Biological P removal with anaerobic selector
- Carriers/Biofilm optimizes nitrification, limiting kinetic rate in BNR
- Selective pollutant degradation by carriers/biofilm: organic compounds, post DN

Small Media Aerobic Reactor Treatment (SMART On-site wastewater Treatment Systems)

- ✓ EHS has DOWN-SIZED this technology to Very Economical *Decentralized* SMALL FLOW and ON-SITE wastewater treatment applications
- ✓ Wisconsin approval has been accomplished for the Small Flow (<1333 P.E.) ON-SITE AEROBIC TREATMENT SYSTEM, with several EHS-SMART-Treatment On-site systems installed since 2001

Small Media Aerobic Reactor Treatment (SMART-Treatment On-site Systems)

EHS SMART System Small Flow Sizing, BOD + Nitrogen Rem

Pop Equiv	WW Q gpd STE	Inf BOD Lbs / day	Reactor gallons	HRT-av Q, hrs	Media, % fill	Tank Depth
5	400	0.77	530	31	10	3.5
50	4,000	7.7	5300	5	64	4
500	40,000	77	8350	5	64	6
1000	80,000	154	16,500	5	64	10

Small Media Aerobic Reactor Treatment

On-site package plants: cluster developments, etc.


PROCESS COMPONENTS

▶ AEROBIC

- BIOFILM CARRIERS
- AERATION SYSTEM
- RETENTION SIEVES

▶ ANOXIC

- BIOFILM CARRIERS
- MECHANICAL MIXERS
- RETENTION SIEVES



Small Media Aerobic Reactor Treatment SMART On-site treatment tank



Water Environment Federation's (1998) MOP 8,
 "Design of Municipal Wastewater Treatment Plants"
Surface Area of Stationary Media Bundles

Typical Wastewater Strength Categories	Surface Area , Sq Ft / Cu Ft Stationary Media Volume
High Strength Waste:	30.5 sq ft/cu ft
Domestic, BOD removal:	36 sq ft/ cu ft
Nitrification applications:	42 sq ft/ cu ft
RBC: – std den / high den	34 sq ft & 56 sq ft / cu ft
Moving Media Comparison, at 66 % Fill Fraction	
BWT-X@198 sq ft/cu ft-bulk	131 sq ft / cu ft- In Reactor
BWT-15@ 253 sq ft/cu ft-bulk	167 sq ft/cu ft- In Reactor

Water Environment Federation's (1998) MOP 8,
 "Design of Municipal Wastewater Treatment Plants"

Typical Wastewater Strength Categories	Surface Area , Sq Ft / Cu Ft Stationary Media Volume
High Strength Waste:	30.5 sq ft/cu ft
Domestic, BOD removal:	36 sq ft/ cu ft
Nitrification applications:	42 sq ft/ cu ft
RBC: – std den / high den	34 sq ft & 56 sq ft / cu ft
Moving Media Comparison, at 66 % Fill Fraction	
BWT-X@198 sq ft/cu ft-bulk	131 sq ft / cu ft- In Reactor
BWT-15@ 253 sq ft/cu ft-bulk	167 sq ft/cu ft- In Reactor
CFIC—BWT-X @ 99% Fill	196 sq ft / cu ft- In Reactor
CFIC—BWT 15 @ 99% Fill	250 sq ft /cu ft- In Reactor




The Next Generation: Continuous Flow Intermittent Cleaning


Doing More with Less—Biowater's Newest Innovation- Better Treatment In An Even Smaller Foot Print: Continuous Flow Intermittent Cleaning

- ❑ The CFIC® reactor contains highly packed biofilm carriers to a degree (typically 90-99% bulk volumetric fill) that little movement of the carriers occurs in the reactor during normal operation.
- ❑ For example using Biowater BWT-X carrier elements---
 - ❑ By increasing bulk volumetric fill from 66 % maximum fill to 99% maximum fill, the reactor biological surface area **INCREASES** from 131 sq ft/cu ft to 196 sq ft/cu ft w/in **same reactor volume— A 50 % INCREASE IN SURFACE AREA!**


CFIC[®]—Normal Operation




CFIC[®]—Intermittent Cleaning





CFIC Reactor---CFIC Elevation



CFIC Reactor---Clean Cycle



Typical CFIC Reactor



Biowater Technology's CFIC® process

- The cleaning cycle is a forward wash cycle (FWC) in that influent wastewater continues to flow into the CFIC® reactor. The cleaning process removes biomass (biofilm and excess sludge) from the biofilm carriers and out of the reactor.
- The turbulence in the reactor may temporarily be increased with an air-lift pump or a propeller to facilitate effective removal of biomass from the carriers
- The carrier shape provides a large void volume (typically an 85% void volume in a 100% fill situation) for growth and accumulation of biomass. The void volume maximizes the run time between cleaning cycles.
- Wastewater treatment with a:

BIOLOGICAL TURBO– More Treatment in Less Space


Biowater Technology's CFIC[®] process

CFIC[®] – The next generation biofilm technology





CFIC[®] biofilm technology is based on biological growth on polyethylene pieces. CFIC[®] provides a protective surface area for the biology to grow and can easily handle extremely high loads of wastewater without problems with clogging or shock.

Normal operation



- Bioreactor is filled >90% with biofilm carriers
- Hindered carrier movement
- Higher O₂ Transfer
- Better transportation of substrate

Open valve: 
Closed valve: 

Biomedia



before...




...and after



cleaning cycle

Intermittent cleaning



- Water level in the bioreactor is increased to let the carriers move
- Accumulated sludge and adhesive biofilm are being removed from the carriers and washed out of the reactor
- The bioreactor is fed by untreated wastewater during washing and is still performing treatment during wash cycle


Wastewater treatment with a biological turbo

CFIC® Biofilm Process


Controlled Wasting of Solids

- High Volatile Solids Content / Renewable Energy Component
- Solids directly to Thickening/Dewatering
- Low Effluent TSS Concentration, 50 – 90% Less Than MBBR
- Filtration for Effluent Reuse
- Continuous Biological Treatment
- Water is dischargeable depending on effluent requirements
- Water does not need to be recirculated
- No Polymer Dosing
- Energy Savings of 20-30%

CFIC®-Parallel Trains, w/ direct flow from CFIC Reactors to micro-filtration or Ultra-fine Membranes



CFIC[®] Pilot Development




CFIC[®]--Pilot Data


- Reactor diameter $\varnothing = 2,5\text{m}$
- Reactor height $H = 6,0\text{ m}$
- Water level: CFIC = 4,0 meter FWC = 5,0 meter
- Filling degree: CFIC = 95 % FWC = 76 %
- Water volume: CFIC = 12,6 m³ FWC = 15,7 m³

- Hydraulic load $Q = 2,0 - 5,0\text{ m}^3/\text{h}$
- COD 2500 – 8000 mg/l ~ 300 - 850kg COD/d
- COD Removal rate $R > 90\%$
- Wastewater temp. $T = 30 - 34\text{ }^{\circ}\text{C}$

CFIC vs. CMFF (conventional MBBR)



COD RR vs. SALR



Sampling & Analytical



- Online Monitoring:
 - Turbidity
 - DO
 - ORP
 - Temperature
 - Nitrate, Ammonia
 - Blower Amps


- Analytical (24-hr Composites and Grabs):
 - TCOD, sCOD, TSS, VSS, Turbidity
 - Correlation of TSS to Turbidity

Wastewater treatment with a biological turbo

Online Turbidity




Online Turbidity Monitoring allows calibration to [TSS] and Process Control



200 FNU
50-60 mg/L TSS


Wastewater treatment with a biological turbo

Turbidity to [TSS]




Wastewater treatment with a biological turbo

Wasting Cycle TSS



Wastewater treatment with a biological turbo

Sludge Volume Index (Waste)



15 October 2011

Sludge Volume 220 mL per 1000 mL

[TSS] = 4,690 mg/L (Waste)

SVI = 47 mL/g

Peak Day

920 mg/L COD

170 mL Sludge Volume

9,000 mg/L TSS (Waste)

SVI = < 20 mL/g

---Summary---

Biowater Technologies CFIC[®] process

- **CFIC[®] Biofilm process- a new development in MBBR technology**
- **The CFIC[®] reactor is filled to a high degree of biofilm carriers (typically 90-95% fill fraction)**
- **The high filling will create a hindered movement of the carriers in the reactor during normal operation**
- **The CFIC[®] process has continuous flow to the bioreactor and intermittent cleaning**

-- GLOBAL PRESENCE --

Biowater Technology & Licensees



GLOBAL PRESENCE



Today's Biowater Technology & Licensees

BIOWATER'S EXPERIENCED TEAM



□ **Laura Marcolini, P.E., M.Sc. - Technical Director, US**

- Process Design Engineer for Kaldnes / Regional Manager for AnoxKaldnes.
- ~ 20 years' water and wastewater process experience



- □ **Jon Gregar Siljudalen, M.Sc. – Chief Technical Officer**
- • Senior Process Engineer Kaldnes Miljøteknologi - AnoxKaldnes
- • Formerly with the municipality of Oslo and Hjeltnes COWI

BIOWATER'S EXPERIENCED TEAM



☐ **Thorbjørn Westrum, M.Sc. (Founder & Board Member)**

- Founder of Kaldnes Miljøteknologi AS and Managing Director from 1990 to 1999.
- Managing Director of Kaldnes, one of the largest shipyards in Norway.



☐ **Terje Andersen (Founder & CEO)**

- Managing Director of Kaldnes Miljøteknologi 1999 - AnoxKaldnes until June 2007.
- ~25 years International Sales and Marketing.

EHS & Biowater - A Good Team

Summary—Fixed Film Moving Media Treatment:

- ✓ Teamed with engineers & companies w/ the most experience & innovative products/processes in fixed film moving media treatment of Water & Wastewater
- ✓ Can supply process knowledge and product for ANY volume or process configuration
- ✓ Provides maintenance agreements where/when needed
- ✓ Strive for BEST Treatment @ Lowest Price, both initial investment and O & M.



Environmental /Health Products & Service

Thank You for the opportunity!